

CASITA® SAND BAG COVER

PRODUCT CATEGORY: OUTDOOR BANNER STAND

PRODUCT CODE: CAS-SBAG



PRODUCT DESCRIPTION

This black nylon sandbag cover is used to protect your sandbag as well as to easily attach your sand bag to one leg of the Casita Canopy for added weight against wind. Included is the cover and hook. Do not fill this cover with sand. To use, feed the hook through the grommet located on the handle of the cover and then close the hook around the leg of the casita canopy. With the cover already on the ground, open the velcro opening and place sandbag* inside the cover. Close velcro opening, and you're done.

DIMENSIONS (EACH SIDE)	11.8" H x 4.3" W
------------------------	------------------

CONSTRUCTION

Black nylon covers with zipper closure and buckle straps

SHIPPING WEIGHTS & DIMENSIONS

Shipping Weight	1 lbs
-----------------	-------

Shipping Dimensions	16" L x 13.5" W Poly bag
---------------------	--------------------------

AVAILABILITY	CA, PA
--------------	--------

CAPACITY	25lbs Total (12.5 lbs each side)
----------	----------------------------------

WIND SPEED RATING	20 - 28 mph
-------------------	-------------



On 10ft Aluminum Casita® frame
(40mm Hex legs)



On 10ft Aluminum Casita® frame
(40mm Hex legs)