

CASITA CANOPY TENTS™ 10FT HEAVY DUTY

OUTDOOR BANNER STAND


PRODUCT CODE: CASDLX-CST10UV



on frame



on graphic



Adjustable Lever



Water Resistant Canopy



Optional Rope and Stakes



Optional Sand Bag



Flag Holder



Nylon Travel Bag

PRODUCT DESCRIPTION

The new Heavy Duty Casita Canopy is our toughest tent yet! Dense aluminum construction makes it sturdy and most durable, especially for outdoor use. The frame is the standard 10 ft. x 10 ft. square and offers a range of heights. Each hexagonal leg has a 48mm girth. Springs in frame add tension to graphic for perfect fit and form.

DISPLAY DIMENSIONS	118"W x 142"H x 118"D
MINIMUM HEIGHT	100"H
MAXIMUM HEIGHT	142"H
LOWEST SETTING TO PEAK	120.25"H
GRAPHIC SIZE	Canopy: 118.75"W x 91.25"H Back Wall: 118.75"W x 88"H Half Wall: 114.5"W x 47"H

GRAPHIC MATERIAL

UV Fabric (water resistant)

GRAPHIC FINISHING

Hemmed around sides

DISPLAY CONSTRUCTION

Aluminum frame (Hex leg thickness: 48mm)

SHIPPING WEIGHTS & DIMENSIONS

Shipping Weight	57 lbs (frame only) 75 lbs (frame, graphic, and bag)
Shipping Dimensions	66"L x 13"W x 13"H (over size)

LARGE QUANTITY FREIGHT

Freight Shipping	12 boxes per 48"L x 40"W x 71"H skid
Freight Weight	729 lbs (frame only) 849 lbs (frame & graphic)

GRAPHIC TURN AROUND TIME

4 business days after proof approval

AVAILABLE ACCESSORIES

Rope and Stakes	Sand Bag
La Caja Hard Case	Flag Holder
AVAILABILITY	CA
WIND RATING	20-28mph

PARTS LIST



(qty 1) Heavy Duty Frame



(qty 1) Travel Bag

CASITA CANOPY TENTS™ 10FT HEAVY DUTY

OUTDOOR BANNER STAND

PRODUCT CODE: CASDLX-CST10UV

SET UP INSTRUCTIONS

(5FT CANOPY SHOWN BELOW)

Step 1

Take your frame and slightly expand it open to expose the corner bars.



Step 2

Take your canopy graphic and place it on top of the frame.




Step 3

Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of loop Velcro sewn to it and each corner of the frame has a strip of hook Velcro.



Step 4

With the canopy securely in position, expand the frame until the corner latches lock into place.



Step 5

Increase the height by extending the lower legs.



Step 6

Pull each leg down until the latch locks into place.



Step 7

Locate the spindle under the canopy, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole. The dome cap will push out the canopy creating tension to flush out any loose areas.



Step 8

The install is complete.

